

The > indicates direction of grain of wood.

SPEAKER BRACKET

- SIZE -LENGTH 19½ in. WIDTH OF SHELF 8½ in. DEPTH AT BACK

- NOTE -

The Hobbies Presentation
Designs are not given
away with back numbers
of Hobbies. Additional
copies may be had from
Hobbies Limited.



ADDRESSES.


ADDRESSES.

All orders by post should be addressed:
Hobbies Limited, Dereham, Norfolk.
Customers residing in the neighbourhood may obtain Tools, Wood and Fittings by calling at the Hobbies Supply Stores:
London: 65 New Oxford Street, W.C.

147 Bishopsgate, E.C.

79 Walworth Road, S.E.
Glasgow: 326 Argyle Street.
Manchester: 10a Piccadilly.
Birmincham: 9a High Street.
Leeds: 10 Queen Victoria Street, Briggate.
Southampton: 25 Bernard Street.
Brighton: 68 London Road.
Sheffield: 214 West Street.
Toronto: 385½ Yonge Street.
And of all Hobbies Authorised Agents.

PRINTED IN ENGLAND



LEDGE TO
FRONT OF SHELF.
(Half only shown)
Cut one 3 in.
thick.

BRACKET



Showing Corner Bracket with Hobbies Cone Loud Speaker No. 1684 in position.

For Prices of Wood and Fittings see current Catalogue, or on application.

BACK -



Shelf (Half only shown) Cut one

CENTRE LINE .



* SCREW

. SCREW



. SEREW

BACK. Cut one \(\frac{3}{8}\) in. thick and bevel the two edges as shown to meet the brackets.

SCREW

SCREW

. SCREW

SCREW

Brackets. Cut one of each and in thick. Dotted lines indicate position of back.